

ivQ-D Installation and Operating Manual

This document provides necessary information for the installation and commissioning of the ivQ Range quarter-turn electric actuator. Each unit is shipped from the factory with initial calibration of cams and switches completed for 0° – 90° operation. However, these are general settings and serve as a starting point for proper calibration of the actuator in its real-world application.

Only competent and trained personnel should install, maintain and operate ivQ actuators. Any work related to an actuator must be carried out in accordance with this manual, accompanied manuals and related codes and regulations. Local workplace health and safety rules should always be followed.

NOTE: Throughout the documentation we reference CLOCKWISE (CW) rotation as moving in the CLOSE direction and COUNTER-CLOCKWISE (CCW) rotation as moving in the OPEN direction.

Receiving / Inspection

- Carefully inspect for shipping damage. Damage to the shipping carton is usually a good indication that it has received rough handling. Report all damage immediately to the freight carrier and your seller.
- After unpacking the product and information packet, please take care to save the shipping carton and any packing material in case of product return or replacement. Verify that the item on the packing list or bill of lading is the same as your own documentation. If there is any discrepancy, please contact the seller.

Storage

- If the actuator cannot be installed immediately, store it in a clean dry environment. The actuator must be protected from excess moisture and dust until you are ready to connect the electrical cables. The actuator should not be installed outside unless it is powered up and has the proper conduit connections.
- If the actuator must be installed but cannot be wired, do not remove the plastic cable entry plugs. When the actuator is wired, it is recommended to replace with water-proof conduit fittings.
- Storage temperature should be within the standard operating temperature range of the actuator.

Before installing the actuator to the valve or damper, check the following:

1. Check the actuator nameplate for the output torque of the actuator. The output torque should be a minimum of 30% greater than the actual maximum requirement of the valve or damper.
2. Check to ensure that the enclosure rating is suitable for the area of installation.
3. Check the wiring diagram as per the wiring diagram code on the nameplate and confirm that it meets with the electrical requirements.
4. Check the actuator nameplate for correct voltage prior to wiring.

Actuator Installation

1. The actuators have been factory calibrated to operate between 0° and 90°. **Most quarter-turn products will not require recalibration of these settings.** If any travel adjustment is necessary, please refer to the “Limit Switch Setting” section below.
2. The actuators are shipped in the full CLOSE (CW) position. The 2 color mechanical position indicator shows “CLOSE”. If the actuator is not in the full CLOSE (CW) position, use the manual override to reposition the actuator (see photo 1). **Please note that the rotating direction of iVQ-D position indicator is opposite to the rotating direction of output drive.**
3. Fully CLOSE the valve or damper to which the actuator is to be mounted. **Note that the actuators rotate CW (as viewed from above the unit) when moving in the CLOSE direction.**
4. Assemble necessary adaption components and attach the actuator to the valve or damper.
5. Tighten mounting bolts, making sure actuator is centered on the valve/damper drive shaft.



Photo 1

6. Check for unobstructed manual operation from fully CW to fully CCW positions. (See Manual Override Section below.)
7. Remove the cover and make the electrical connections as per the wiring diagram. Typical connections have AC Neutral or DC (-) to terminal 1 and AC Live or DC (+) to terminal 3 or 4. Connection to terminal 3 to OPEN (CCW). Connection to terminal 4 to CLOSE (CW).
8. For models where auxiliary switches are provided, terminals A - F are for 2 x SPDT adjustable auxiliary switches. They are dry type Form C rated 3A @ 250V AC max. Terminals A, B & C are for the OPEN position auxiliary switch (adjustable). Terminals A, E & F are for the CLOSE position auxiliary switch (adjustable).
9. Connect the ground wire to PE inside the electric actuator.
10. Replace cover and secure cover screws.
11. Do NOT apply power at this time. See "Commissioning" section below.
12. Check below explanation of Duty Cycle. The intended service should not go above the maximum duty cycle as noted on the actuator nameplate.



Photo 2

Installation Notes

- These actuators are designed to be used between a horizontal and upright position. Do NOT mount the assembly with the actuator top below a horizontal position.
- When installing conduit, use proper techniques for entry into the actuator. It is preferred that the conduit entries face downward. Use drip loops to prevent conduit condensate from entering the actuator. Use proper fittings to maintain the NEMA 4X integrity of the housing. Seal (pot) the conduit entries.
- Use proper wire size to prevent actuator failure. All terminals accept 14 -18AWG solid/stranded wire.
- Do NOT touch any components on the PCB with metal tools or bare hands.
- The internal heater is to be used in all applications. Do NOT install the actuator outdoors or in humid environments unless it is powered up and the heater is functioning.
- Do NOT parallel wire multiple actuators together without utilizing isolation relays. If this is your intention, please contact Innovative Actuation Incorporated for a multiple actuator parallel wiring diagram.

Duty cycle

Duty cycle is the percent of time that an actuator spends running as a fraction of the total time. Duty cycle is directly related to heat; excessively repositioning an actuator typically results in motor overheating, which can cause permanent damage and/or reduced service life.

Duty cycle can be calculated as follows:

(example iVQ-D Range actuator running 27 seconds ON and 64 seconds OFF).

Runtime = 27s, Total time = 27s + 64s = 91s, therefore this duty cycle would be 30% (27/91). Standard duty with iVQ Range actuators is 30% so it is within the allowed limit. 64 seconds is the minimum off time in this example.

Manual Override

Utilize the manual override (5mm female hex drive) to check for unobstructed manual operation from fully CLOSE (CW) to fully OPEN (CCW) positions BEFORE applying power to the unit (see photo 3). This actuator can also be purchased without the manual override.

Warning: DO NOT operate manual override when power is present. Gear train damage and personal injury may occur.

Do not use powered tools to turn the manual override as it will DAMAGE the gear train or motor and VOID the warranty.



Photo 3

Commissioning

This procedure will assume that the actuator is installed correctly both mechanically and electrically with correct power and has been manually cycled.

Electrically test Full OPEN (CCW) and CLOSE (CW) positions

A. Apply power to terminals marked 1 & 3 (OPEN)

- The actuator will drive to the full OPEN (CCW) position (as viewed from ABOVE the actuator).
- If this is NOT the correct stop position, refer to the “Limit Switch Setting” section in this manual to reset LS1.

B. Apply power to terminals marked 1 & 4 (CLOSE)

- The actuator will drive to the full CLOSE (CW) position (as viewed from ABOVE the actuator).
- If this is NOT the correct stop position, refer to the “Limit Switch Setting” section in this manual to reset LS2.

Limit Switch Setting

The travel cams are set to control the open and closed position of the valve. The position is set to stop the travel of the actuator when the travel cams activate the limit switch. Standard is two limit switches (LS1 & LS2), one for open, one for closed. LS1 & LS2 limit the maximum range by disabling the electric motor. LS3 & LS4 are optional. See photo 4. They allow external equipment to confirm that the valve has reached the fully open and fully closed positions. **Care must be taken to ensure that LS3 & LS4 are set to trip prior to LS1 & LS2 so that proper end of travel indication is provided.** The travel cams can be adjusted with a 2.5mm Allen key.

- **To set LS1, the OPEN position (Full CCW Position):**
 - Turn power off and use manual override to turn valve to the open position.
 - Remove cover and loosen the set screw on the bottom cam TC1.
 - Rotate cam counter-clockwise to reset the switch contact.
 - Then, slowly rotate cam clockwise until a light click is heard.
 - Securely tighten the cam and apply power to check the end position.

- **To set LS2, the CLOSE position (Full CW Position):**
 - Turn power off and use manual override to turn valve to the closed position.
 - Loosen the set screw on cam TC2.
 - Rotate cam clockwise to reset the switch contact.
 - Then, slowly rotate cam counter-clockwise until a light click is heard.
 - Securely tighten the cam and apply power to check the end position.



Photo 4

- **To set LS3 - OPEN (Auxiliary Switch):**

- Ensure that the actuator is in the fully CCW position.
- Loosen the set screw on cam TC3.
- Rotate cam counter-clockwise to reset the switch contact.
- Then, slowly rotate cam clockwise until a light click is heard.
- Slowly continue to rotate in the same direction for approx. 3°.
- Securely tighten the cam and apply power to ensure that this switch trips before it reaches the end position.

- **To set LS4 - CLOSE (Auxiliary Switch):**

- Ensure that the actuator is in the fully CW position.
- Loosen the set screw on cam TC4.
- Rotate cam clockwise to reset the switch contact.
- Then, slowly rotate cam counter-clockwise until a light click is heard.
- Slowly continue to rotate in the same direction for approx. 3°.
- Securely tighten the cam and apply power to check that this switch trips before it reaches the end position.

Troubleshooting

Problem	Remedies
<p>Motor does not operate and overheats.</p>	<p>There may be a valve issue. Inspect/replace the valve.</p>
	<p>Check for any obstructions in the flowline.</p>
	<p>Motor stem or bearing may be broken. Replace parts.</p>
	<p>Check to see if the closed limit switch is set properly.</p>
	<p>Possibly due to a wiring issue. Check terminal numbers 3 & 4 to see if they are wired correctly.</p>
<p>The actuator operates but the motor is hot.</p>	<p>The actuator may be operating too frequently. Check if operation is within duty rating of actuator.</p>
	<p>Overload issue. Runtime may be longer than specified. New valve may be required.</p>
	<p>The voltage may be under/over rated. Check the supply voltage.</p>
<p>The valve does not move when given a signal or in manual operation.</p>	<p>Check installation between the actuator and valve as it may not be assembled properly.</p>
	<p>Verify that the setscrews of the travel cams are tightened.</p>
	<p>The torque requirement of the valve may be larger than the output torque of the actuator. Check sizing to confirm correct actuator selection for the valve.</p>
<p>When operating two or more actuators simultaneously, one of the motors are hot or working abnormally.</p>	<p>There may be a parallel wiring connection issue. Check current values and install a relay.</p>