



iVM Range Wiring Diagram Matrix

Actuator Model	Voltage	Control	Options	Control Voltage	Indication Contacts	Modulation Input	Position Feedback Output	Communication	iVM Range
M	1 - 110V/1/60 2 - 220V/1/60 3 - 220V/3/60 4- 380V/3/60	A - ON/OFF, Modulating and BUS communication	A - None B - Heater	A - 24V DC B - 110V AC	A - 4 Relays (Channel 1) B - 8 Relays (Channel 1 & 2)	1 - 4-20mA (Default) 2 - 1 - 5V 3 - 2 - 10V	1 - 4-20mA (Default) 2 - 1 - 5V 3 - 2 - 10V	N - None (Default) 1 - Modbus Enabled 2 - Profibus Enabled 3 - Hart Enabled	See Wiring Diagram For Applicable Range